



	36	37	38	39	40	41
	Z6suvky	Z6suvky	Z6suvky	Z6suvky	Z6suvky	Rezerva
	0,5	0,5	0,5	0,5	0,5	
	CYKY-J 3x2,5 WL	CYKY-J 3x2,5 WL	CYKY-J 3x2,5 WL	CYKY-J 3x2,5 WL	CYKY-J 3x2,5 WL	
	RS2/36	RS2/37	RS2/38	RS2/39	RS2/40	
	302	307	308	309	309	

SCHÉMA ROZVÁDĚČE RS2

č.výkresu

D1.4-04

měřitko

--